

<u>Electronic Lock Operating Instructions</u> <u>-LG Safe Guard Lock with Combination Lock Back Up-</u> Vault Doors

Operating Instructions

- -Enter combination on the keypad Lock will signal when proper combination has been entered
- -Turn combination dial one turn clockwise until dial stops
- -Turn safe handle
- *Repeated beeping during an opening indicates that the Battery is low and should be replaced
- *Invalid combination entry: Lock signals three times
- *Wrong try penalty entry of three consecutive invalid combinations will initiate a 5 minute lock out period, during which time the LED flashes red at 10 second intervals

Changing Combination

(Lock signals twice after each valid entry)

- *Change combination with door open*
- Enter six zeros
- Enter existing combination
- Enter new six digit combination TWICE

Before closing door

Enter existing combination to verify proper operation

Changing Batteries

- -Remove keypad by gently lifting straight up and tilting back
- -Please note keypad cable only has a few inches of free length
- -Connect one 9-Volt Alkaline battery (Duracell only) to each battery clip
- -Insert batteries into bottom of housing
- -Replace by placing the keypad on its mounting pins and sliding down until keypad is firmly locked into position